


# Installation guide

## Solenoid valve


### Type EV258B

032R9283


032R9283




**1**




**2**




**3**



**4**



**5**



**6**

