

Voltage link, internal, incommmer below

Part no. +IZM-DTP-PFBT
 Catalog No. 122990

Delivery program

Accessories			Options / accessories trip blocks
Accessories			Add-on function for control unit power monitoring
			Voltage tap on incoming unit at bottom: Internally, voltage is tapped at the lower (instead of the upper) contacts. Voltage tapping is relevant for power measurement.
For use with			IZM...-P... (Digitrip 1150)

Design verification as per IEC/EN 61439

Technical data for design verification			
Operating ambient temperature min.		°C	-25
Operating ambient temperature max.		°C	70