



## Programming software for easy400/500/600/700/800/MFD-Titan

**Part no.** EASY-SOFT-PRO  
**Catalog No.** 266040  
**EL-Nummer (Norway)** 4519720



### Delivery program

Subrange		Programming accessories
Function		Programming and visualisation software
Software		13 installation languages Operating systems: Windows XP SP3, Windows Vista (32-bit), Windows 7 (32-bit + 64-bit), Windows 8 (32-bit + 64-bit), Windows 10 (32-bit + 64-bit)
For use with		easy400/500/600/700/800/MFD-...-CP8/CP10

### Technical data ETIM 7.0

PLC's (EG000024) / Programming- and engineering software (EC000809)		
Electric engineering, automation, process control engineering / Control / Control software / Programming and engineering software (control) (ec1@ss10.0.1-27-24-25-01 [AKE560015])		
With editor for programming language IL (Instruction List)		No
With editor for programming language LD (Ladder Diagram)		Yes
With editor for programming language FBD (Function Block Diagram)		No
With editor for programming language ST (structured text)		No
With editor for programming language SFC (Sequential Function Chart)		No
With editor for programming language Flowchart		No
With editor for manufacturer specific programming language		Yes
Suitable for operating system Windows 9x		No
Suitable for operating system Windows NT		No
Suitable for operating system Windows 2000		No
Suitable for operating system Windows XP		Yes
Suitable for operating system Windows ME		No
Suitable for operating system Windows CE		No
Suitable for operating system Linux		No
Suitable for operating system Windows Vista		Yes
Suitable for operating system Windows 2003 Server		No
Suitable for operating system Windows 7		Yes
Suitable for operating system Windows 8		Yes
Suitable for other operating system		Yes
Object library		Integrated
Integrated diagnosis function		Yes
Integrated configuration function		Yes
Integrated evaluation function		Yes
Integrated application configuration function		Yes
Integrated data detection function		Yes
Integrated communication function		Yes
Technology function integrated		No
Put into operation function integrated		Yes
Simulation function integrated		Yes
Integrated motion function		Yes
Integrated analysis function		Yes
Integrated position function		Yes
Maintenance function integrated		Yes
In accordance with IEC 1131-3 (DIN EN 61131-3)		No
Suitable for safety functions		No
SIL according to IEC 61508		None

## Approvals

North America Certification

UL/CSA certification not required

## Assets (links)

### Manuals

MN04902001Z\_EN (English)

MN05002001Z\_EN (English)

## Additional product information (links)

### Manual "easy800 control relays" MN04902001Z (AWB2528-1423)

Handbuch „Steuerrelais easy800“  
MN04902001Z (AWB2528-1423) - Deutsch [ftp://ftp.moeller.net/DOCUMENTATION/AWB\\_MANUALS/MN04902001Z\\_DE.pdf](ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN04902001Z_DE.pdf)

Manual "easy800 control relays" MN04902001Z  
(AWB2528-1423) - English [ftp://ftp.moeller.net/DOCUMENTATION/AWB\\_MANUALS/MN04902001Z\\_EN.pdf](ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN04902001Z_EN.pdf)

### Manual "MFD-Titan multi-function display" MN05002001Z (AWB2528-1480)

Handbuch „Multifunktions-Display MFD-Titan“  
MN05002001Z (AWB2528-1480) - Deutsch [ftp://ftp.moeller.net/DOCUMENTATION/AWB\\_MANUALS/MN05002001Z\\_DE.pdf](ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN05002001Z_DE.pdf)

Manual "MFD-Titan multi-function display"  
MN05002001Z (AWB2528-1480) - English [ftp://ftp.moeller.net/DOCUMENTATION/AWB\\_MANUALS/MN05002001Z\\_EN.pdf](ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN05002001Z_EN.pdf)

### Manual "easy500, easy700 control relays" MN05013003Z (AWB2528-1508)

Handbuch „Steuerrelais easy500, easy700“  
MN05013003Z (AWB2528-1508) - Deutsch [ftp://ftp.moeller.net/DOCUMENTATION/AWB\\_MANUALS/MN05013003Z\\_DE.pdf](ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN05013003Z_DE.pdf)

Manual "easy500, easy700 control relays"  
MN05013003Z (AWB2528-1508) - English [ftp://ftp.moeller.net/DOCUMENTATION/AWB\\_MANUALS/MN05013003Z\\_EN.pdf](ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN05013003Z_EN.pdf)