



Remote testing module, max. 400V-AC, 0.5A, 0.5HP

**Part no.** Z-FW/050  
**Catalog No.** 248301  
**Alternate Catalog No.** Z-FW/050

Similar to illustration

### Delivery program

|                            |                |   |  |
|----------------------------|----------------|---|--|
| Basic function             |                |   | Accessories for residual current circuit-breakers              |
| Basic function accessories |                |   | Remote test module   |
| Application                |                |   | Switchgear for industrial and advanced commercial applications |
| Rated fault current        | $I_{\Delta N}$ | A | 0.5  |
| Product range              |                |   | Accessory  |
| Side mounting              |                |   | for fitting on left to: FI                                     |

### Design verification as per IEC/EN 61439

| Technical data for design verification        |           |    |      |
|---|-----------|----|------|
| Heat dissipation per pole, current-dependent  | $P_{vid}$ | W  | 0.02 |
| Equipment heat dissipation, current-dependent | $P_{vid}$ | W  | 0.02 |
| Operating ambient temperature min.            |           | °C | -5   |
| Operating ambient temperature max.            |           | °C | 40   |

### Technical data ETIM 7.0

| Devices for distribution board-/surface mounting (EG000062) / Auxiliary device for distribution board devices (EC001286)  |  |   |                      |
|---|--|---|----------------------|
| Electric engineering, automation, process control engineering / Electrical installation, device / Breaker switch component / Auxiliary contact unit for distribution board (ecl@ss10.0.1-27-14-35-02 [AKE327013]) |  |   |                      |
| Device fitting  |  |   | Earth leakage switch |
| Additional equipment  |  |   | Monitoring unit      |
| Attached at delivery  |  |   | No                   |
| Assembly width (TE)   |  |   | 0.5                  |
| Number of contacts as normally open contact   |  |   | 0                    |
| Number of contacts as normally closed contact   |  |   | 0                    |
| Number of contacts as change-over contact   |  |   | 0                    |
| Number of fault-signal switches   |  |   | 0                    |
| Rated switch current  |  | A | 0                    |
| Rated voltage   |  | V | 0                    |
| Voltage type for actuating  |  |   | AC                   |
| With auto test for earth leakage function   |  |   | No                   |
| Suitable for max. number of poles main contact unit (total)   |  |   | 0                    |
| Suitable for max. current main contact unit   |  | A | 0                    |

## Dimensions

