



**Memory card for easy800-standard/MFD-CP8, 256kB**

**Part no.** EASY-M-256K  
**Catalog No.** 256279  
**EL-Nummer (Norway)** 4520977

**Delivery program**

For use with		easy800 MFD-...-CP8
Memory size	KByte	256-kB module
<b>Information relevant for export to North America</b>		
Product Standards IEC/EN see Technical Data; UL 508; CSA C22.2 No. 142-M1987; CSA C22.2 No. 213-M1987; CE marking		
UL File No. E135462		
UL Category Control No. NRAQ		
CSA File No. 012528		
CSA Class No. 2258-02		
North America Certification UL listed, CSA certified		
Degree of Protection IEC: IP20, UL/CSA Type: -		

**Design verification as per IEC/EN 61439**

Technical data for design verification		
Operating ambient temperature min.	°C	-25
Operating ambient temperature max.	°C	55

**Technical data ETIM 7.0**

PLC's (EG000024) / PLC memory card (EC000192)		
Electric engineering, automation, process control engineering / Control / Programmable logic control (SPS) / SPS memory unit (ecl@ss10.0.1-27-24-22-12 [AKE535014])		
Type of memory		EEPROM
Memory size	kByte	256

**Approvals**

Product Standards		IEC/EN see Technical Data; UL 508; CSA C22.2 No. 142-M1987; CSA C22.2 No. 213-M1987; CE marking
UL File No.		E135462
UL Category Control No.		NRAQ
CSA File No.		012528
CSA Class No.		2258-02
North America Certification		UL listed, CSA certified
Degree of Protection		IEC: IP20, UL/CSA Type: -

**Additional product information (links)**

<b>Instruction leaflet "easy control relays" IL05013012Z (AWA2528-1979)</b>	
Instruction leaflet "easy control relays" IL05013012Z (AWA2528-1979)	<a href="https://es-assets.eaton.com/DOCUMENTATION/AWA_INSTRUCTIONS/IL05013012Z2010_11.pdf">https://es-assets.eaton.com/DOCUMENTATION/AWA_INSTRUCTIONS/IL05013012Z2010_11.pdf</a>
Instruction leaflet "easy control relays" IL05013012Z (AWA2528-1979)	<a href="https://es-assets.eaton.com/DOCUMENTATION/AWA_INSTRUCTIONS/IL05013012Z2018_02.pdf">https://es-assets.eaton.com/DOCUMENTATION/AWA_INSTRUCTIONS/IL05013012Z2018_02.pdf</a>
<b>Instruction leaflet "Multi-function display, easy control relays" IL05013014Z (AWA2528-2019)</b>	
Instruction leaflet "Multi-function display, easy control relays" IL05013014Z (AWA2528-2019)	<a href="https://es-assets.eaton.com/DOCUMENTATION/AWA_INSTRUCTIONS/IL05013014Z2018_02.pdf">https://es-assets.eaton.com/DOCUMENTATION/AWA_INSTRUCTIONS/IL05013014Z2018_02.pdf</a>
<b>Manual "easy800 control relays" MN04902001Z (AWB2528-1423)</b>	

Handbuch „Steuerrelais easy800“ MN04902001Z (AWB2528-1423) - Deutsch	<a href="https://es-assets.eaton.com/DOCUMENTATION/AWB_MANUALS/MN04902001Z_DE.pdf">https://es-assets.eaton.com/DOCUMENTATION/AWB_MANUALS/MN04902001Z_DE.pdf</a>
Manual "easy800 control relays" MN04902001Z (AWB2528-1423) - English	<a href="https://es-assets.eaton.com/DOCUMENTATION/AWB_MANUALS/MN04902001Z_EN.pdf">https://es-assets.eaton.com/DOCUMENTATION/AWB_MANUALS/MN04902001Z_EN.pdf</a>
<b>Manual "MFD-Titan multi-function display" MN05002001Z (AWB2528-1480)</b>	
Handbuch „Multifunktions-Display MFD-Titan“ MN05002001Z (AWB2528-1480) - Deutsch	<a href="https://es-assets.eaton.com/DOCUMENTATION/AWB_MANUALS/MN05002001Z_DE.pdf">https://es-assets.eaton.com/DOCUMENTATION/AWB_MANUALS/MN05002001Z_DE.pdf</a>
Manual "MFD-Titan multi-function display" MN05002001Z (AWB2528-1480) - English	<a href="https://es-assets.eaton.com/DOCUMENTATION/AWB_MANUALS/MN05002001Z_EN.pdf">https://es-assets.eaton.com/DOCUMENTATION/AWB_MANUALS/MN05002001Z_EN.pdf</a>