

**Braking resistance, 470 Ohm, 140W**

**Part no.** DE4-BR1-470-140  
**Article no.** 219497  
**Catalog No.** -


## Delivery programme

For use with			DF51 DV51 DF6 DV6
--------------	--	--	----------------------------

## Technical data ETIM 4.0

Type of accessory		Braking resistance
-------------------	--	--------------------

## Dimensions



## Additional product information (links)

<b>AWA8240-1725 Braking resistor, Power resistor</b>	
AWA8240-1725 Braking resistor, Power resistor	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWA_INSTRUCTIONS/17250406.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWA_INSTRUCTIONS/17250406.pdf</a>
<b>AWB8230-1540 Vector Frequency Inverters</b>	
AWB8230-1540 Vektor-Frequenzumrichter - Deutsch	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1540d.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1540d.pdf</a>
AWB8230-1540 Vector Frequency Inverters - English	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1540g.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1540g.pdf</a>
<b>AWB8230-1580 Vector Frequency Inverter Training Guide</b>	

AWB8230-1580 Kurzanleitung Vektor-Frequenzumrichter - Deutsch	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1580d.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1580d.pdf</a>
AWB8230-1580 Vector Frequency Inverter Training Guide - English	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1580g.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1580g.pdf</a>
<b>AWB8230-1541 Frequency inverters</b>	
AWB8230-1541 Frequenzumrichter - Deutsch	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1541d.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1541d.pdf</a>
AWB8230-1541 Frequency inverters - English	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1541g.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1541g.pdf</a>
<b>AWB8230-1579 Frequency Inverter Training Guide</b>	
AWB8230-1579 Kurzanleitung Frequenzumrichter - Deutsch	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1579d.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1579d.pdf</a>
AWB8230-1579 Frequency Inverter Training Guide - English	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1579g.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1579g.pdf</a>
<b>AWB8230-1415 Vector Frequency Inverters</b>	
AWB8230-1415 Vektor-Frequenzumrichter - Deutsch	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1415d.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1415d.pdf</a>
AWB8230-1415 Vector Frequency Inverters - English	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1415g.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1415g.pdf</a>
AWB8230-1415 Convertitore di frequenza vettoriale - italiano	<a href="ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1415i.pdf">ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/h1415i.pdf</a>