


- Blinds ensure that the detectors' detection area is adapted to the local circumstances. Sources of interference or unwanted areas can be eliminated from the area subject to motion detection. Blinds are included with the product. More can be ordered, if needed.

Blinds for B.E.G. ceiling-mounted motion detectors

LUXOMAT® PD3N, PD2, PD4 – SM-version – Part nr. 92260




The blinds have nominal breaks at regular distances. The detection area can therefore be accurately adapted to your needs.




LUXOMAT® PD4 – FC- and FM-version – Part nr. 32701




The blinds have nominal breaks at regular distances. The detection area can therefore be accurately adapted to your needs.



LUXOMAT® Mini motion detector PD9 – Part nr. 32702



LUXOMAT® Mini motion detector PD9-GH for great heights – Part nr. 33207



- Installation note - Arc extinction kit
 - In some cases of switching inductive loads e.g. relays, rockerswitches, fluorescent lamps, transformers etc, the motion detector may be retriggered again due to the high inductive voltage. In those cases the above kit is recommended to be switched parallel to the load i.e. between L' and Neutral.
 - Wiring diagrams on page 143!

Arc extinction kit for B.E.G. ceiling-mounted motion detectors

LUXOMAT® Arc extinction kit – Part nr. 10880



L 62 x W 39 x H 24 mm

LUXOMAT® Mini-Arc extinction kit – Part nr. 10882



L 50 x W 22 x H 10 mm