


Installation guide

Solenoid valve


Type EV225B

032R9281


032R9281




1




2




3



4



5



6

