



REFRIGERATION AND
AIR CONDITIONING

INSTRUCTIONS

AK - USB converter




080R9296



R18PJ200

AK => USB => PC

AK => PC: max. 15 m



R18PJ200 02-2014