


Data sheet – Spare parts and accessories

**Gas detecting sensors**  
Types GDA, GDC, GDHC, GDHF, GDH



| Description   | Fig. # | Qty. | Code no. |
|---|--------|------|----------|
| <b>GD Tester all models. To test mother PCB at Sensor PCB replacement</b> |        |      |          |
| Beaker M42  | 1      | 1    | 148H5230 |
| EC/SC/CT-Adapter. Fit Beaker M42  | 1      | 1    |          |
| M35 Adapter. Fit Beaker M42   | 1      | 1    |          |
| <b>GD Ampoules</b>  |        |      |          |
| GD Ampoules 100 ppm ammonia   | 1      | 10   | 148H5234 |
| GD Ampoules 1000 ppm ammonia  | 1      | 10   | 148H5235 |
| GD Ampoules 2000 ppm CO <sub>2</sub>                                      | 1      | 10   | 148H5236 |
| <b>Remote LCD display</b>   |        |      |          |
| Remote LCD display IP 41  | 2      | 1    | 148H5238 |

| Description                          | Fig. # | Qty. | Code no. |
|--------------------------------------|--------|------|----------|
| <b>GD mother PCB</b>                 |        |      |          |
| GD mother PCB all models             | 3      | 1    | 148H5232 |
| <b>GD Tester for mother PCB</b>      |        |      |          |
| GD Tester for mother PCB, all models | 3      | 1    | 148H5239 |