



Coupling piece, enclosure with enclosure

Part no. VS-TR-CI
Catalog No. 002330

EL-Nummer (Norway) 2502089

Delivery program

Product range		Ci insulated enclosures
Basic function		Distribution board assembly
Product function		Accessories
Accessories		Assembly bracket
Information about equipment supplied		Including fixing sundries
For use with		For the connection of distribution boards and for transport units For enclosure assembly at transport splits
Notes		
Additional accessories → #095750		

Technical data ETIM 7.0

Cabinet enclosures (EG000011) / Component for arrangement / baying system (switchgear cabinet) (EC002622)		
Electric engineering, automation, process control engineering / Electrical cabinet, housing, rack / Elements for switching cabinet, housing, rack / Component for arrangement/baying system (electrical cabinet) (ecl@ss10.0.1-27-18-28-13 [ACN631012])		
Model		Coupling piece, top
Width	mm	37
Height	mm	16
Depth	mm	7
Material		Steel
Colour		Other
RAL-number		7035

Additional product information (links)

Declaration of conformity	ftp://ftp.moeller.net/DOCUMENTATION/PDF/ci_ce.pdf
allowInterrupt=1&RevisionSelectionMethod=LatestReleased&noSaveAs=0&RenderModelCertification xEnergy Safety Ci	http://www.eaton.eu/DE/ecm/idcplg?IdcService=GET_FILE&model certification xEnergy Safety Ci
allowInterrupt=1&RevisionSelectionMethod=LatestReleased&noSaveAs=0&RenderModelCertification xEnergy Safety Ci Save time – we assist you with expert pre-assembly	http://www.eaton.eu/DE/ecm/idcplg?IdcService=GET_FILE&Save time – we assist you with expert pre-assembly
allowInterrupt=1&RevisionSelectionMethod=LatestReleased&noSaveAs=0&RenderModelCertification xEnergy Safety Ci product information xEnergy Safety Ci	http://www.eaton.eu/DE/ecm/idcplg?IdcService=GET_FILE&product information xEnergy Safety Ci
tool for calculating the power loss for switching device combinations	http://www.eaton.eu/DE/Europe/Electrical/CustomerSupport/ConfigurationTools/TCTool/index.htm
configurator - xEnergy family	http://www.eaton.eu/DE/Europe/Electrical/CustomerSupport/ConfigurationTools/xEnergyMainSupport/index.htm