


PRODUCT-DETAILS

# 8554 BL

Cover switch Symbol "4-level switch" for Level switch, Turn button White - Sky Niessen



## General Information

Extended Product Type	8554 BL
Product ID	2CLA855400A1101
EAN	8427238139883
Catalog Description	Cover switch Symbol "4-level switch" for Level switch, Turn button White - Sky Niessen
Long Description	Color: Soft White Cover plate for rotatory switch code: 8154

## Installation

Instructions and Manuals	2CLX850009A1001
--------------------------	-----------------

## Popular Downloads

Marketing Video	9AKK106930A1594 9AKK108468A9590
-----------------	------------------------------------

## Technical

Data Sheet, Technical	9AKK107046A0356
-----------------------	-----------------

Information	
Application	Level switch
Design Range	Sky Niessen
Type of Fastening	Clamp
Surface Finishing	Untreated Glossy
Material	Plastic Thermoplastic
Legend	Symbol "4-level switch"
Model Number	Turn button
RAL Number	RAL 9010 - Pure White
Color	White

Environmental

Ambient Air Temperature	Operation -5 ... +35 °C Storage -5 ... +50 °C
Degree of Protection	IP20
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Product Net Width	0.073 m
Product Net Height	0.033 m
Product Net Depth / Length	0.073 m
Product Net Weight	0.024 kg

Certificates and Declarations

Declaration of Conformity - CE	No declaration needed
--------------------------------	-----------------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
WEEE Category	Product Not in WEEE Scope
CN8	85389099
UNSPSC	39121704

---

## Categories

---

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Mechanical Controls

