

PRODUCT-DETAILS

# 8554 PL

## Cover switch Symbol "4-level switch" for Level switch, Turn button Silver - Sky Niessen



### General Information

Extended Product Type	8554 PL
Product ID	2CLA855400A1301
EAN	8427238139890
Catalog Description	Cover switch Symbol "4-level switch" for Level switch, Turn button Silver - Sky Niessen
Long Description	Color: SilverCover plate for rotatory switch code: 8154

### Installation

Instructions and Manuals	2CLX850009A1001
--------------------------	-----------------

### Popular Downloads

Marketing Video	9AKK106930A1594 9AKK108468A9590
-----------------	------------------------------------

### Technical

Data Sheet, Technical Information	9AKK107046A0356
Application	Level switch
Design Range	Sky Niessen

Type of Fastening	Clamp
Surface Finishing	Decor Matt
Material	Plastic Thermoplastic
Legend	Symbol "4-level switch"
Model Number	Turn button
Color	Silver

---

## Environmental

Ambient Air Temperature	Operation -5 ... +35 °C Storage -5 ... +50 °C
Degree of Protection	IP20
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

---

## Dimensions

Product Net Width	0.073 m
Product Net Height	0.033 m
Product Net Depth / Length	0.073 m
Product Net Weight	0.024 kg

---

## Certificates and Declarations

Declaration of Conformity - CE	No declaration needed
-----------------------------------	-----------------------

---

## Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
WEEE Category	Product Not in WEEE Scope
CN8	85389099
UNSPSC	39121704

---

## Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Mechanical Controls

