

PRODUCT-DETAILS

8554 NS

Cover switch Symbol "4-level switch" for Level switch, Turn button Black - Sky Niessen



General Information

Extended Product Type	8554 NS
Product ID	2CLA855400A1501
EAN	8427238139913
Catalog Description	Cover switch Symbol "4-level switch" for Level switch, Turn button Black - Sky Niessen
Long Description	Color: Soft Black Cover plate for rotatory switch code: 8154

Installation

Instructions and Manuals	2CLX850009A1001
--------------------------	-----------------

Popular Downloads

Marketing Video	9AKK106930A1594 9AKK108468A9590
-----------------	------------------------------------

Technical

Data Sheet, Technical	9AKK107046A0356
-----------------------	-----------------

Information

Application	Level switch
Design Range	Sky Niessen
Type of Fastening	Clamp
Surface Finishing	Decor Matt
Material	Plastic Thermoplastic
Legend	Symbol "4-level switch"
Model Number	Turn button
Color	Black

Environmental

Ambient Air Temperature	Operation -5 ... +35 °C Storage -5 ... +35 °C
Degree of Protection	IP20
RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
RoHS Information	2CLC855400A1501
REACH Declaration	9AKK108467A7464
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Product Net Width	0.073 m
Product Net Height	0.033 m
Product Net Depth / Length	0.073 m
Product Net Weight	0.024 kg

Certificates and Declarations

Declaration of Conformity - CE	No declaration needed
--------------------------------	-----------------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
WEEE Category	Product Not in WEEE Scope
CN8	85389099
UNSPSC	39121704

Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Mechanical Controls

