

PRODUCT-DETAILS

8560.2 BL

Cover dimmer for Dimmer Turn button White - Sky Niessen



General Information

Extended Product Type	8560.2 BL
Product ID	2CLA856020A1101
EAN	8427238134963
Catalog Description	Cover dimmer for Dimmer Turn button White - Sky Niessen
Long Description	Cover plate with rotary knob for dimmer and DALI code: 8160, 8160.2, 8160.3, 8160.5, 8160.7, 8160.8, 8160.9, 8161.4, 8161.5 & 8161.8 Color: Soft White Included: indicator neon lamp

Installation

Instructions and Manuals	2CLX850009A1001
--------------------------	-----------------

Popular Downloads

Marketing Video	9AKK106930A1594 9AKK108468A9590
-----------------	------------------------------------

Technical

Data Sheet, Technical	9AKK107046A0356
-----------------------	-----------------

Information	
Application	Dimmer
Design Range	Sky Niessen
Type of Fastening	Clamp
Surface Finishing	Untreated Glossy
Material	Plastic Thermoplastic
Legend	None
Model Number	Turn button
RAL Number	RAL 9010 - Pure White
Color	White
Application Function	Electrical Load and Light Control

Environmental

Ambient Air Temperature	Operation -5 ... +35 °C Storage -5 ... +50 °C
Degree of Protection	IP20
RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
RoHS Information	2CLC856020A1101
REACH Declaration	9AKK108467A7464
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Product Net Width	0.081 m
Product Net Height	0.078 m
Product Net Depth / Length	0.131 m
Product Net Weight	0.021 kg

Ordering

Replaced Product ID (OLD)	2CL0856021
------------------------------	------------

Certificates and Declarations

Declaration of Conformity - CE	No declaration needed
-----------------------------------	-----------------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
WEEE Category	Product Not in WEEE Scope
CN8	85389099
UNSPSC	39121704

Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Electronic Controls

