

PRODUCT-DETAILS

8572 CN

Frame 2gang Black - Sky Niessen



Informazioni generali

Tipo	8572 CN
ID prodotto	2CLA857200A3101
EAN	8427238136295
Descrizione catalogo	Frame 2gang Black - Sky Niessen
Descrizione	Color: Black Glass Size (height x width): 86 x 157 mm Surface: bright black glass

Installation

Istruzioni e manuali	2CLX850009A1001
----------------------	-----------------

Download Piu' Usati

Marketing Video	9AKK106930A1594 9AKK108468A9590
-----------------	------------------------------------

ABB EcoSolutions

ABB EcoSolutions	Si
------------------	----

Circular Value

Circular Design Principles Recyclability Rate	Design for Closing Resource Loops - Standard EN45555 - 94 %
Sustainable Material Content	Mechanically Recycled Polymer - 37.77 %
Sustainable Material Content in Packaging	Recycled Cardboard - 91.66 %

Eco Transparency

Dichiarazione prodotto ambientale - EPD	9AKK108468A8662
---	-----------------

Dati tecnici

Scheda tecnica	9AKK107046A0356
Number of Gangs	2
Design Range	Sky Niessen
Type of Fastening	Clamp
Mounting Orientation	Horizontal Vertical
Finitura superficie	Untreated Glossy
Materiale	Glass
Label Space Provided	No
Colore	Black

Dati ambientali

Temperatura ambiente	In funzione -5 ... +35 °C In magazzino -5 ... +50 °C
Grado di protezione	IP20
Dichiarazione RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informazioni RoHS	2CLC857200A3101
REACH Declaration	9AKK108467A7464
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensioni

Larghezza prodotto	157 mm
Altezza prodotto	86 mm
Profondità prodotto	8.5 mm
Peso netto prodotto	0.114 kg

Ordinazione

ID prodotto sostituito (VECCHIO)	2CL0857231
----------------------------------	------------

Certificati e dichiarazioni (numero del documento)

Dichiarazione di
conformità - CE

No declaration needed

Classificazioni

ETIM 8	EC000007 - Cover frame for domestic switching devices
ETIM 9	EC000007 - Cover frame for domestic switching devices
Categoria RAEE	Prodotto non in ambito RAEE
Tipo di oggetto design	85389099
UNSPSC	39121704

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CLA810100A1001	Switch 1-way Off switch 1-pole with LED exchangeable	8101	1	pezzo (i)
2CLA850100A2501	Rocker switch None for Switch/push button, Single rocker Black - Sky Niessen	8501 CN	1	pezzo (i)
2CLA810200A1001	Switch 2-way Two-way switch with LED exchangeable	8102	1	pezzo (i)
2CLA811000A1001	Intermediate switch Intermediate switch with LED exchangeable	8110	1	pezzo (i)
2CLA810400A1001	Push button 1 NO 0 NC 1 CO	8104	1	pezzo (i)
2CLA850400A1501	Rocker push button Symbol "bell" for Switch/push button, Single rocker Black - Sky Niessen	8504 NS	1	pezzo (i)
2CLA811100A1001	Switch 1-way Series switch	8111	1	pezzo (i)
2CLA851100A2501	Rocker switch None for Switch/push button, Two-part rocker Black - Sky Niessen	8511 CN	1	pezzo (i)
2CLA812200A1001	Switch 2-way Alternating-/alternating switch	8122	1	pezzo (i)
2CLA818800A1001	Socket outlet Protective contact (SCHUKO) No color - Platform 8100	8188	1	pezzo (i)
2CLA858800A2501	Cover socket outlet Socket outlet Central cover plate Black - Sky Niessen	8588 CN	1	pezzo (i)
2CLA811700A1001	Phone outlet For data connection housing 1gang No color	8117	1	pezzo (i)
2CLA851700A1501	Phone outlet Data connection 1 gang Black - Sky Niessen	8517 NS	1	pezzo (i)
2CLA815170A1001	TV/SAT outlet End socket No color	8151.7	1	pezzo (i)
2CLA855010A1501	Cover TV-R/SAT SAT 2 gang Black - Sky Niessen	8550.1 NS	1	pezzo (i)
2CLA811900A1001	Buzzer No color - Platform 8100	8119	1	pezzo (i)
2CLA852900A1501	Cover buzzer Loudspeaker Central cover plate Black - Sky Niessen	8529 NS	1	pezzo (i)
2CLA850000A1501	Blank cover Blind plate None Black - Sky Niessen	8500 NS	1	pezzo (i)
2CLA810450A1001	Push button 1 NO 0 NC 1 CO	8104.5	1	pezzo (i)
2CLA850440A1501	Rocker push button Symbol "light" for Switch/push button, Single rocker Black - Sky Niessen	8504.4 NS	1	pezzo (i)
2CLA814410A1001	Blind switch	8144.1	1	pezzo (i)
2CLA854400A2501	Rocker blind switch for Venetian blind Two-part rocker Black - Sky Niessen	8544 CN	1	pezzo (i)
2CLA814400A1001	Push button	8144	1	pezzo (i)
2CLA851810A1501	Cover data Data connection 1 gang Black - Sky Niessen	8518.1 NS	1	pezzo (i)
2CLA851820A1501	Cover data Data connection 2 gang Black - Sky Niessen	8518.2 NS	1	pezzo (i)
2CLA856020A1501	Cover dimmer for Dimmer Turn button Black - Sky Niessen	8560.2 NS	1	pezzo (i)
2CLA818500A1001	USB charger Breakout cable with USB AA No color	8185	1	pezzo (i)
2CLA858500A1501	Cover USB charger USB 1 gang Black - Sky Niessen	8585 NS	1	pezzo (i)

Categorie

Prodotti di bassa tensione → Wiring Accessories - Light Switch Ranges → Frames

