

PRODUCT-DETAILS

## 8573 FR

# Frame 3gang Wood - Sky Niessen



### Informazioni generali

|                      |   |
|----------------------|---|
| Tipo                 | 8573 FR   |
| ID prodotto          | 2CLA857300A2001   |
| EAN                  | 8427238139012   |
| Descrizione catalogo | Frame 3gang Wood - Sky Niessen  |
| Descrizione          | Color: Ash<br>Size (height x width): 86 x 228 mm<br>Surface: tinted ash |

### Installation

|                      |                 |
|----------------------|-----------------|
| Istruzioni e manuali | 2CLX850009A1001 |
|----------------------|-----------------|

### Download Piu' Usati

|                 |                                    |
|-----------------|------------------------------------|
| Marketing Video | 9AKK106930A1594<br>9AKK108468A9590 |
|-----------------|------------------------------------|

### Dati tecnici

|                |                 |
|----------------|-----------------|
| Scheda tecnica | 9AKK107046A0356 |
|----------------|-----------------|

|                      |                        |
|----------------------|------------------------|
| Number of Gangs      | 3                      |
| Design Range         | Sky Niessen            |
| Type of Fastening    | Clamp                  |
| Mounting Orientation | Horizontal<br>Vertical |
| Finitura superficie  | Untreated<br>Matt      |
| Materiale            | Wood                   |
| Label Space Provided | No                     |
| Colore               | Wood                   |

## Dati ambientali

|   |  |
|---|--|
| Temperatura ambiente                        | In funzione -5 ... +35 °C<br>In magazzino -5 ... +35 °C                |
| Grado di protezione                         | IP20   |
| Dichiarazione RoHS                          | Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019 |
| Informazioni RoHS                           | 2CLC857300A2001  |
| REACH Declaration                           | 9AKK108467A7464  |
| Conflict Minerals Reporting Template (CMRT) | 9AKK108468A3363  |

## Dimensioni

|                     |         |
|---------------------|---------|
| Larghezza prodotto  | 228 mm  |
| Altezza prodotto    | 86 mm   |
| Profondità prodotto | 8.5 mm  |
| Peso netto prodotto | 0.06 kg |

## Ordinazione

|                                  |            |
|----------------------------------|------------|
| ID prodotto sostituito (VECCHIO) | 2CL0857320 |
|----------------------------------|------------|

## Certificati e dichiarazioni (numero del documento)

|                                  |                       |
|----------------------------------|-----------------------|
| Dichiarazione di conformità - CE | No declaration needed |
|----------------------------------|-----------------------|

## Classificazioni

|                        |   |
|------------------------|---|
| ETIM 8                 | EC000007 - Cover frame for domestic switching devices |
| ETIM 9                 | EC000007 - Cover frame for domestic switching devices |
| Categoria RAEE         | Prodotto non in ambito RAEE                           |
| Tipo di oggetto design | 85389099  |
| UNSPSC                 | 39121704  |

## Accessories

| Identifier      | Description   | Type      | Quantity | Unit Of Measure |
|-----------------|---|-----------|----------|-----------------|
| 2CLA810100A1001 | Switch 1-way Off switch 1-pole with LED exchangeable  | 8101      | 1        | pezzo (i)       |
| 2CLA850100A1101 | Rocker switch None for Switch/push button, Single rocker White - Sky Niessen                | 8501 BL   | 1        | pezzo (i)       |
| 2CLA810200A1001 | Switch 2-way Two-way switch with LED exchangeable   | 8102      | 1        | pezzo (i)       |
| 2CLA811000A1001 | Intermediate switch Intermediate switch with LED exchangeable                               | 8110      | 1        | pezzo (i)       |
| 2CLA810400A1001 | Push button 1 NO 0 NC 1 CO  | 8104      | 1        | pezzo (i)       |
| 2CLA850400A1101 | Rocker push button Symbol "bell" for Switch/push button, Single rocker White - Sky Niessen  | 8504 BL   | 1        | pezzo (i)       |
| 2CLA811100A1001 | Switch 1-way Series switch  | 8111      | 1        | pezzo (i)       |
| 2CLA851100A1101 | Rocker switch None for Switch/push button, Two-part rocker White - Sky Niessen              | 8511 BL   | 1        | pezzo (i)       |
| 2CLA812200A1001 | Switch 2-way Alternating-/alternating switch  | 8122      | 1        | pezzo (i)       |
| 2CLA818800A1001 | Socket outlet Protective contact (SCHUKO) No color - Platform 8100                          | 8188      | 1        | pezzo (i)       |
| 2CLA858800A1101 | Cover socket outlet Socket outlet Central cover plate White - Sky Niessen                   | 8588 BL   | 1        | pezzo (i)       |
| 2CLA811700A1001 | Phone outlet For data connection housing 1gang No color                                     | 8117      | 1        | pezzo (i)       |
| 2CLA851700A1101 | Cover data Data connection 1 gang White - Sky Niessen                                       | 8517 BL   | 1        | pezzo (i)       |
| 2CLA815170A1001 | TV/SAT outlet End socket No color   | 8151.7    | 1        | pezzo (i)       |
| 2CLA855010A1101 | Cover TV-R/SAT SAT 2 gang White - Sky Niessen   | 8550.1 BL | 1        | pezzo (i)       |
| 2CLA811900A1001 | Buzzer No color - Platform 8100   | 8119      | 1        | pezzo (i)       |
| 2CLA852900A1101 | Cover buzzer Loudspeaker Central cover plate White - Sky Niessen                            | 8529 BL   | 1        | pezzo (i)       |
| 2CLA850000A1101 | Blank cover Blind plate None White - Sky Niessen  | 8500 BL   | 1        | pezzo (i)       |
| 2CLA810450A1001 | Push button 1 NO 0 NC 1 CO  | 8104.5    | 1        | pezzo (i)       |
| 2CLA850440A1101 | Rocker push button Symbol "light" for Switch/push button, Single rocker White - Sky Niessen | 8504.4 BL | 1        | pezzo (i)       |
| 2CLA814410A1001 | Blind switch  | 8144.1    | 1        | pezzo (i)       |
| 2CLA854400A1101 | Rocker blind switch for Venetian blind Two-part rocker White - Sky Niessen                  | 8544 BL   | 1        | pezzo (i)       |
| 2CLA814400A1001 | Push button   | 8144      | 1        | pezzo (i)       |
| 2CLA851810A1101 | Cover data Data connection 1 gang White - Sky Niessen                                       | 8518.1 BL | 1        | pezzo (i)       |
| 2CLA851820A1101 | Cover data Data connection 2 gang White - Sky Niessen                                       | 8518.2 BL | 1        | pezzo (i)       |
| 2CLA856020A1101 | Cover dimmer for Dimmer Turn button White - Sky Niessen                                     | 8560.2 BL | 1        | pezzo (i)       |
| 2CLA818500A1001 | USB charger Breakout cable with USB AA No color - Platform 8100                             | 8185      | 1        | pezzo (i)       |
| 2CLA858500A1101 | Cover USB charger USB 1 gang(s) White - Sky Niessen   | 8585 BL   | 1        | pezzo (i)       |

---

## Categorie

---

Prodotti di bassa tensione → Wiring Accessories - Light Switch Ranges → Frames

