
PRODUCT-DETAILS

8574 CB

Frame 4gang White - Sky Niessen



Informazioni generali

Tipo	8574 CB
ID prodotto	2CLA857400A3001
EAN	8427238136363
Descrizione catalogo	Frame 4gang White - Sky Niessen
Descrizione	Color: White Glass Size (height x width): 86 x 299 mm Surface: bright white glass

Installation

Istruzioni e manuali	2CLX850009A1001
----------------------	-----------------

Download Piu' Usati

Marketing Video	9AKK106930A1594 9AKK108468A9590
-----------------	------------------------------------

ABB EcoSolutions

ABB EcoSolutions	Si
------------------	----

Circular Value

Circular Design Principles Recyclability Rate	Design for Closing Resource Loops - Standard EN45555 - 94 %
Sustainable Material Content	Mechanically Recycled Polymer - 37.77 %
Sustainable Material Content in Packaging	Recycled Cardboard - 91.66 %

Eco Transparency

Dichiarazione prodotto ambientale - EPD	9AKK108468A8662
---	-----------------

Dati tecnici

Scheda tecnica	9AKK107046A0356
Number of Gangs	4
Design Range	Sky Niessen
Type of Fastening	Clamp
Mounting Orientation	Horizontal Vertical
Finitura superficie	Untreated Glossy
Materiale	Glass
Label Space Provided	No
Colore	White

Dati ambientali

Temperatura ambiente	In funzione -5 ... +35 °C In magazzino -5 ... +50 °C
Grado di protezione	IP20
Dichiarazione RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informazioni RoHS	2CLC857400A3001
REACH Declaration	9AKK108467A7464
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensioni

Larghezza prodotto	299 mm
Altezza prodotto	86 mm
Profondità prodotto	8.5 mm
Peso netto prodotto	0.204 kg

Ordinazione

ID prodotto sostituito (VECCHIO)	2CL0857430
----------------------------------	------------

Certificati e dichiarazioni (numero del documento)

Dichiarazione di conformità - CE	No declaration needed
----------------------------------	-----------------------

Classificazioni

ETIM 8	EC000007 - Cover frame for domestic switching devices
ETIM 9	EC000007 - Cover frame for domestic switching devices
Categoria RAEE	Prodotto non in ambito RAEE
Tipo di oggetto design	85389099
UNSPSC	39121704

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CLA810100A1001	Switch 1-way Off switch 1-pole with LED exchangeable	8101	1	pezzo (i)
2CLA850100A2101	Rocker switch None for Switch/push button, Single rocker White - Sky Niessen	8501 CB	1	pezzo (i)
2CLA810200A1001	Switch 2-way Two-way switch with LED exchangeable	8102	1	pezzo (i)
2CLA811000A1001	Intermediate switch Intermediate switch with LED exchangeable	8110	1	pezzo (i)
2CLA810400A1001	Push button 1 NO 0 NC 1 CO	8104	1	pezzo (i)
2CLA850400A1101	Rocker push button Symbol "bell" for Switch/push button, Single rocker White - Sky Niessen	8504 BL	1	pezzo (i)
2CLA811100A1001	Switch 1-way Series switch	8111	1	pezzo (i)
2CLA851100A2101	Rocker switch None for Switch/push button, Two-part rocker White - Sky Niessen	8511 CB	1	pezzo (i)
2CLA812200A1001	Switch 2-way Alternating-/alternating switch	8122	1	pezzo (i)
2CLA818800A1001	Socket outlet Protective contact (SCHUKO) No color - Platform 8100	8188	1	pezzo (i)
2CLA858800A2101	Cover socket outlet Socket outlet Central cover plate White - Sky Niessen	8588 CB	1	pezzo (i)
2CLA811700A1001	Phone outlet For data connection housing 1gang No color	8117	1	pezzo (i)
2CLA851700A1101	Cover data Data connection 1 gang White - Sky Niessen	8517 BL	1	pezzo (i)
2CLA815170A1001	TV/SAT outlet End socket No color	8151.7	1	pezzo (i)
2CLA855010A1101	Cover TV-R/SAT SAT 2 gang White - Sky Niessen	8550.1 BL	1	pezzo (i)
2CLA811900A1001	Buzzer No color - Platform 8100	8119	1	pezzo (i)
2CLA852900A1101	Cover buzzer Loudspeaker Central cover plate White - Sky Niessen	8529 BL	1	pezzo (i)
2CLA850000A1101	Blank cover Blind plate None White - Sky Niessen	8500 BL	1	pezzo (i)
2CLA810450A1001	Push button 1 NO 0 NC 1 CO	8104.5	1	pezzo (i)
2CLA850440A1101	Rocker push button Symbol "light" for Switch/push button, Single rocker White - Sky Niessen	8504.4 BL	1	pezzo (i)
2CLA814410A1001	Blind switch	8144.1	1	pezzo (i)
2CLA854400A2101	Rocker blind switch for Venetian blind Two-part rocker White - Sky Niessen	8544 CB	1	pezzo (i)
2CLA814400A1001	Push button	8144	1	pezzo (i)
2CLA851810A1101	Cover data Data connection 1 gang White - Sky Niessen	8518.1 BL	1	pezzo (i)
2CLA851820A1101	Cover data Data connection 2 gang White - Sky Niessen	8518.2 BL	1	pezzo (i)
2CLA856020A1101	Cover dimmer for Dimmer Turn button White - Sky Niessen	8560.2 BL	1	pezzo (i)
2CLA818500A1001	USB charger Breakout cable with USB AA No color - Platform 8100	8185	1	pezzo (i)
2CLA858500A1101	Cover USB charger USB 1 gang(s) White - Sky Niessen	8585 BL	1	pezzo (i)

Categorie

Prodotti di bassa tensione → Wiring Accessories - Light Switch Ranges → Frames

