

PRODUCT-DETAILS

8530 NS

Electronic rocker for Switch/push button Single push button Black - Sky Niessen



Informações gerais

Tipo de produto alargado	8530 NS
ID do produto	2CLA853000A1501
EAN	8427238136011
Descrição do catálogo	Electronic rocker for Switch/push button Single push button Black - Sky Niessen
Descrição longa	Electronic rocker for dimmer, blind and time delayed switch control code: 8130, 8130.1, 8130.2 & 8130.3

Installation

Instruções e Manuais	2CLX850009A1001
----------------------	-----------------

Popular Downloads

Marketing Video	9AKK106930A1594 9AKK108468A9590
-----------------	------------------------------------

Technical

Ficha de dados,	9AKK107046A0356
-----------------	-----------------

informação técnica

Aplicação	Switch/push button
Design Range	Sky Niessen
Type of Fastening	Clamp
Acabamento de superfície	Decor Matt
Material	Plastic Thermoplastic
Legend	None
Model Number	Single push button
Color	Black
Number of Batteries	0
Application Function	Blind / Shutter / Shading Control Electrical Load and Light Control

Environmental

Temperatura do ar ambiente	Operation -5 ... +35 °C Storage -5 ... +35 °C
Grau de proteção	IP20
Estado RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informação RoHS	2CLC853000A1501
REACH Declaration	9AKK108467A7464
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Largura Líquida do Produto	0.073 m
Altura Líquida do Produto	0.033 m
Profundidade/Comprimento Líquidos do Produto	0.073 m
Peso Líquido do Produto	0.059 kg

Certificates and Declarations

Declaração de conformidade -CE	9AKK106713A1745
--------------------------------	-----------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
Categoria REEE	5. Small Equipment (No External Dimension More Than 50 cm)
REEE B2C / B2B	Business To Consumer
CN8	85389099
UNSPSC	39121704

Categorias

Produtos e Sistemas de Baixa Tensão → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Electronic Controls

