

PRODUCT-DETAILS

8554 NS

Cover switch Symbol "4-level switch" for Level switch, Turn button Black - Sky Niessen



Informações gerais

Tipo de produto alargado	8554 NS
ID do produto	2CLA855400A1501
EAN	8427238139913
Descrição do catálogo	Cover switch Symbol "4-level switch" for Level switch, Turn button Black - Sky Niessen
Descrição longa	Color: Soft Black Cover plate for rotatory switch code: 8154

Installation

Instruções e Manuais	2CLX850009A1001
----------------------	-----------------

Popular Downloads

Marketing Video	9AKK106930A1594 9AKK108468A9590
-----------------	------------------------------------

Technical

Ficha de dados, informação técnica	9AKK107046A0356
Aplicação	Level switch

Design Range	Sky Niessen
Type of Fastening	Clamp
Acabamento de superfície	Decor Matt
Material	Plastic Thermoplastic
Legend	Symbol "4-level switch"
Model Number	Turn button
Color	Black

Environmental

Temperatura do ar ambiente	Operation -5 ... +35 °C Storage -5 ... +35 °C
Grau de proteção	IP20
Estado RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informação RoHS	2CLC855400A1501
REACH Declaration	9AKK108467A7464
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Largura Líquida do Produto	0.073 m
Altura Líquida do Produto	0.033 m
Profundidade/Comprimento Líquidos do Produto	0.073 m
Peso Líquido do Produto	0.024 kg

Certificates and Declarations

Declaração de conformidade -CE	No declaration needed
--------------------------------	-----------------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
Categoria REEE	Product Not in WEEE Scope
CN8	85389099
UNSPSC	39121704

Categorias

Produtos e Sistemas de Baixa Tensão → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Mechanical Controls

