



## Automatización Eléctrica

At the end of this document you will find links to products related to this catalog. You can go directly to our shop by clicking HERE. <u>HERE</u>

Laser Photoelectric Sensor with Built-in Amplifier

# E3Z-Laser

## *Compact photoelectric sensor with LASER light*

The E3Z LASER sensor in compact plastic housing features visible LASER light for precision positioning and detection applications.

- Visible LASER light for precision positioning and small object detection
- High power LED for high functional reserve




## **Features**

### Through-beam and Retroreflective Sensors


Greatly Enhanced Beam Visibility for Easier Optical Axis Adjustment of Sensors

- The optical design maximizes the linear propagation of laser beams. Red laser beams (class 1) can be precisely aligned on the targeted position.
- The functional reserve of the rated through-beam sensing distance of 60 m provides sufficient allowance, enabling Through-beam Models to be used reliability even in dusty environments.



Reliable Detection of Small Objects and Narrow Gaps with the Small Spot

- The spot diameter for Through-beam and Retro-reflective Models is 5 mm (a typical example at 3 m), making it possible to detect small workpieces at long distances.
- The sensing distance for Retro-reflective Models is 15 m (when an E39-R1S Reflector is used). This is the longest leeway in the industry.



## **BGS Models**

Long-distance Sensing at 300 mm (White Paper)



## A Low Black/White Error for Applications with Mixed Colors

• A black/white error as low as 5% makes detection and operation more stable.




## Easy Detection of Small Workpieces and Minor Differences in Levels with the Small Spot

- Stable detection is possible with no influence from a glossy background frame.
- The spot diameter for BGS models is 0.5 mm (typical example at 300 mm). Combined with an hysteresis of only 5%, even minute differences can be detected.
- Models with a response time of 0.5 ms (E3Z-LL\_3/\_8) are available as standard models for fast-moving objects.



## Advanced Optical Technology of the E3Z Laser

Laser beam directional deviation can be suppressed and spot diameters can be freely customized. This is achieved through high-precision alignment technology based on LD and emitter lens modularization. The lens position can be adjusted inline. (Patent pending.)



## Laser Diagram Conceptual Diagram

By precisely adjusting the emitter lens in the vertical, horizontal, and depth directions, alignment can be achieved with minimal directional deviation (to  $\pm 1$  degree).

Red light

## **Ordering Information**

## Sensors

Sensing method	Appearance	Connection method	Response	Sonsing distance	Мо	del
Sensing method	Appearance	Connection method	time	Sensing distance	NPN output	PNP output
		Pre-wired (2 m)*1		*2	E3Z-LT61	E3Z-LT81
Through-beam		Standard M8 Connector		<b></b> 60 m	E3Z-LT66	E3Z-LT86
		Pre-wired (2 m)*1		*4	E3Z-LR61	E3Z-LR81
Retro-reflective with MSR function	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Standard M8 Connector	1 ms	15 m (Using E39-R1)           7 m (Using E39-R12)           7 m (Using E39-R12)           7 m (200 mm)           7 m (200 mm)	E3Z-LR66	E3Z-LR86
		Pre-wired (2 m)*1		00 to 10 mm	E3Z-LL61	E3Z-LL81
Distance-settable		Standard M8 Connector		20 to 40 mm (Min. distance set) 20 to 300 mm (Max. distance set)	E3Z-LL66	E3Z-LL86
(BGS Models)		Pre-wired (2 m)*1			E3Z-LL63	E3Z-LL83
		Standard M8 Connector	0.5 ms	25 to 40 mm (Min. distance set) 25 to 300 mm (Max. distance set)	E3Z-LL68	E3Z-LL88

\*1. Pre-wired Models with a 0.5-m cable are also available for these products. When ordering, specify the cable length by adding "0.5M" to the end of the model number (e.g., E3Z-LT61 0.5M).

M12 Pre-wired Connector Models are also available. When ordering, add "-M1J" to the end of the model number (e.g., E3Z-LT61-M1J). The cable is 0.3 m long. The following connection forms are also available. Ask your OMRON representative for details.
Pre-wired Models with 1-m or 5-m cables
Pre-wired Connector Models with M8 4-pin connectors, M8 3-pin connectors.
\*2. Consult with your OMRON representative if a distance of more than 10 m is required. Models with large custom-size spots can be produced. These make optical

axis adjustment easier and allow the beam to be received more stably by the Receiver even if vibration is present.

\*3. \*4. The Reflector is sold separately. Select the Reflector model most suited to the application.

Values in parentheses indicate the minimum required distance between the Sensor and Reflector.

## Accessories (Order Separately)

Slits (for E3Z-LT

Slit width	Sensing distance	Minimum detectable object (typical)	Model	Contents
0.5 mm dia.	3 m	0.1 mm dia.	E39-S65A	One set (contains Slits for both the Emitter and Receiver)

Reflectors (for E3Z-LR

Name	Sensing distance (typical)	Model	Remarks
	15 m (300 mm)	E39-R1S	Retro-reflective models are not provided with     Reflectors.
Reflector	7 m (200 mm)	E39-R12	<ul> <li>Separate the Sensor and the Reflector by at least the</li> </ul>
	7 m (200 mm)		<ul><li>distance given in parentheses.</li><li>The MSR function is enabled.</li></ul>

## **Mounting Brackets**

Appear- ance	Model	Quantity	Remarks	Appear- ance	Model	Quantity	Remarks
	E39-L153	1	Mounting Brackets		E39-L98	1	Metal Protective Cover Bracket *1
line -	E39-L104	1	Mounting Drackets		E39-L150	1 set	(Sensor adjuster)
	E39-L43	1	Horizontal Mounting Bracket*1		E39-L151	1 set	Easily mounted to the alumi- num frame rails of conveyors and easily adjusted.
	E39-L142	1	Horizontal Protective Cover Bracket*1		E39-L151	1 361	For left to right adjustment
6- 10-	E39-L44	1	Rear Mounting Bracket		E39-L144	1	Compact Protective Cover Bracket (For E3Z only) *1

\*1. Cannot be used for Standard Connector models.

Note: When using Through-beam models, order one bracket for the Receiver and one for the Emitter.

## Sensor I/O Connectors

(Please refer to accessary datasheet E26E-EN-01 for a complete overview of all available sensor connectors)

Size	Cable	Appearance		Cable type		Model
			$\langle$	2 m		XS3F-M421-402-A
Mo		Straight	5 m	4	XS3F-M421-405-A	
M8			<u> </u>	2 m	4-wire	XS3F-M422-402-A
	Standard	L-shaped	5 m		XS3F-M422-405-A	
		Straight	2 m		XS2F-D421-DC0-A	
M12 (For -M1J			5 m	3-wire	XS2F-D421-GC0-A	
models)				2 m		XS2F-D422-DC0-A
		L-shaped		5 m		XS2F-D422-GC0-A

## Ratings and Specifications

Sensi	ng		Retro-reflective with	Distance esttab	la (BCS madala)		
metho		Through-beam	MSR function	Distance-settab	le (BGS models)		
Respor	1		Standard response		High-speed response		
Model	NPN output	E3Z-LT61/-LT66	E3Z-LR61/-LR66	E3Z-LL61/-LL66	E3Z-LL63/-LL68		
Item	PNP output	E3Z-LT81/-LT86	E3Z-LR81/-LR86	E3Z-LL81/-LL86	E3Z-LL83/-LL88		
Sensing di	stance	60 m *1	0.3 to 15 m (when using E39-R1) 0.2 to 7 m (when using E39-R12) 0.2 to 7 m (when using E39-R6)	White paper (100 $\times$ 100 mm): 20 to 300 mm Black paper (100 $\times$ 100 mm): 20 to 160 mm	White paper (100 $\times$ 100 mm): 25 to 300 mm Black paper (100 $\times$ 100 mm): 25 to 100 mm		
Set distanc	e range			White paper (100 $\times$ 100 mm): 40 to 300 mm Black paper (100 $\times$ 100 mm): 40 to 160 mm	White paper $(100 \times 100 \text{ mm})$ :           40 to 300 mm           Black paper $(100 \times 100 \text{ mm})$ :           40 to 100 mm		
Spot diamete	r (typical)	5 mm dia	a. at 3 m	0.5 mm dia	. at 300 mm		
Standard sens	sing object	Opaque: 12 mm dia. min.	Opaque: 75 mm dia. min.	-			
Minimum de object (ty		6 mm dia. opaqı	ue object at 3 m	0.2 mm dia. stainless-st	eel pin gauge at 300 mm		
Differentia	l travel		-	5% max. of	set distance		
Black/whit	e error			5% at 160 mm	5% at 100 mm		
Directiona	l angle	Receiver: 3 to 15°					
Light source (w	vavelength)	Rec	I LED (655 nm), JIS CLas	s 1, IEC Class 1, FDA Clas	ss II		
Power suppl	y voltage		12 to 24 VDC±10%, r	ipple (p-p): 10% max.			
Current cons	sumption	Emitter: 15 mA 30 mA max.					
Control o	output	Load power supply vo	oltage: 26.4 VDC max., Lo	ad current: 100 mA max.,	Open collector output		
Residual outp	ut voltage	Load current of less than 10 mA: 1 V max. Load current of 10 to 100 mA: 2 V max.					
Output mode	switching		Switch to change between light-ON and dark-ON				
Protection	circuits	Reversed power supply polarity protection, Output short-circuit pro- tection, and Reversed output polarity protection		polarity protection, Outpu evention, and Reversed ou			
Response	e time	С	Operate or reset: 1 ms max	κ.	Operate or reset: 0.5 ms max.		
Sensitivity ac		One-turn	adjuster	Five-turn end	lless adjuster		
Ambient illu				np: 3,000 lx max.			
(Receiver	,	Operating: 1	=	,000 lx max. o 70 °C (with no icing or c	ondoneation)		
Ambient temper	_			to 95% (with no icing or c			
Ambient humi Insulation re		Operating: 3		· •	unuensau011)		
			20 MΩ min. at 500 VDC				
Dielectric s Vibration re	-	1,000 VAC, 50/60 Hz for 1 min					
Shock resi		Destruction: 10 to 55 Hz, 1.5 mm double amplitude for 2 hours each in X, Y, and Z directions Destruction: 500 m/s <sup>2</sup> 3 times each in X, Y, and Z directions					
Degree of p		Des			6110		
Connection		IP67 (IEC 60529)           Pre-wired cable (standard length: 2 m): E3Z-L□1/-L□3           Standard M8 Connector: E3Z-L□6/-L□8					
Indica	tor	Operation indicator (orange) Stability indicator (green) Emitter for Through-bream Models has power indicator (orange) only.					


Sensing method		0	Through-beam	Retro-reflective with MSR function	le (BGS models)		
	Respor	nse		Standard response		High-speed response	
	Model	NPN output	E3Z-LT61/-LT66	E3Z-LR61/-LR66 E3Z-LL61/-LL66		E3Z-LL63/-LL68	
Item	Model	PNP output	E3Z-LT81/-LT86	E3Z-LR81/-LR86	E3Z-LL81/-LL86	E3Z-LL83/-LL88	
Weight	(2111)		Approx. 120 g	Approx. 65 g			
state)	(packed Standard Connector		Approx. 30 g	Approx. 20 g			
		Case	PBT (polybutylene terephthalate)				
Material	Material Lens		Modified polyarylate resin	Methacrylic resin Modified polyarylate resin			
Accessories (Neither Reflec			(Neither Reflecto	Instruction manual ors nor Mounting Brackets are provided with any of the above models.)			

\*1. Consult with your OMRON representative if a distance of more than 10 m is required. Models with large custom-size spots can be produced. These make optical axis adjustment easier and allow the beam to be received more stably by the Receiver even if vibration is present.

Note: An emission stop function can be added to Through-beam Models as a custom function. Ask your OMRON representative for details.


## Parallel Operating Range

## Through-beam Models




## Operating Range at a Set Distance of 300 mm

## BGS Models




## Retro-reflective Models for transparent objects E3Z-LR




Operating Range at a Set Distance of 40 mm

## BGS Models


E3Z-LL



## Excess Gain vs. Set Distance



## **Retro-reflective Models**



### **Close Range Characteristics**

#### **BGS Models**

E3Z-LL□1/-LL□6

300 mm 200 160 mm 150 100 40 mm 40 mm 50 12 mr 10 mm 0 mm 10 n 0 White Black White Black paper Setting: 300 mm paper Setting: 160 mm paper Setting: 40 mm paper Setting: 40 mm

#### E3Z-LL 3/-LL 8

E3Z-LL 3/-LL 8

Sensing distance (mm)

40

30


20

10

0

White Veneer

paper




White Paper with a Set Distance of 40 mm

## Sensing Distance vs. Sensing Object Material

**BGS Models** 


E3Z-LL□1/-LL□6

White Paper with a Set Distance of 40 mm



## E3Z-LL01/-LL06

White Paper with a Set Distance of 300 mm





paper

Black SUS

rubber


Mirror

Material

surface


Card- Black

board




#### Emission Spot Diameter vs. Distance

Through-beam and Retro-reflective Models




## BGS Models (Same for All Models)




E3Z-LL 3(LL 8)

## Error vs. Distance


## BGS Models





#### Angle Characteristics (Vertical) BGS Models


## E3Z-LL



## Angle Characteristics (Vertical)

**BGS Models** 





## I/O Circuit Diagrams

## NPN output

Model	Operation mode	Timing charts	Mode selector switch	Output circuit
	Light ON	Incident light No incident light Operation indicator ON (orange) OFF Output transistor ON OFF Load Operate (e.g., relay) Reset (Between brown and black leads)	L side (LIGHT ON)	Through-beam Receivers, Retro-reflective Models Operation Idicator
E3Z-LT61 E3Z-LT66 E3Z-LR61 E3Z-LR66	Dark ON	Incident light No incident light Operation indicator ON (orange) OFF Output transistor OFF Load Operate (e.g., relay) Reset (Between brown and black leads)	D side (DARK ON)	M12 Connector Pin Arrangement
		Through-beam Emitter Power indicator (orange) Photo-elec- tric Sensor Main Circuit	Brown	M12 Connector Pin Arrangement Pin Arrangement Pin Arrangement Pin S 2 and 4 are not used.
E3Z-LL61 E3Z-LL66	Light ON	Operation indicator (orange) Output transistor (e.g., relay) Reset (Between brown and black leads)	L side (LIGHT ON)	Operation Indicator (Orange)
E3Z-LL63 E3Z-LL68	Dark ON	Operation ON indicator ON (orange) OFF Dutput ON transistor OFF Load Operate (e.g., relay) Reset (Between brown and black leads)	D side (DARK ON)	M12 Connector Pin Arrangement


## PNP output

Model	Operation mode	Timing chart	Mode selector switch	Output circuit
E3Z-LT81 E3Z-LT86 E3Z-LR81 E3Z-LR86	Light ON	Incident light No incident light Operation indicator ON (orange) OFF Output transistor OR Defret Load Operate (Between blue and black leads)	L side (LIGHT ON)	Through-beam Receivers, Retro-reflective Models Operation indicator (Orange) Photo- lectric Sensor Main Control Unit of the formation Control Main Control Stability (Control Main Control Main Control Stability (Control Main Control Main Control Main Control Main Control
	Dark ON	Incident light No incident light Operation indicator ON (orange) OFF Output transistor ON OFF Load Operate (e.g., relay) Reset (Between blue and black leads)	D side (DARK ON)	M12 Connector Pin Arrangement
		Through-beam Emitter Power indicator (orange) Photo-elec- tric Sensor Main Circuit	Brown Blue	M12 Connector Pin Arrangement M8 4-pin Connector Pin Arrangement Di Arrangement


Model	Operation mode	Timing chart	Mode selector switch	Output circuit
E3Z-LL81 E3Z-LL86	Light ON	Operation ON indicator ON (orange) OFF Utansistor OFF Load (e.g., relay) Operate (Between blue and black leads)	L side (LIGHT ON)	Operation Indicator (Orange)
E3Z-LL86 E3Z-LL83 E3Z-LL88	Dark ON	Operation ON indicator ON (orange) OFF Output ON Load Operate (e.g., relay) Reset (Between blue and black leads)	D side (DARK ON)	M12 Connector Pin Arrangement

## Plugs (Sensor I/O Connectors)

#### M8 4-pin Connectors



#### M12 Connectors



## Nomenclature

## Sensors with Sensitivity Adjustment and Mode Selector Switch

Through-beam Models E3Z-LT (Receiver)


## Retro-reflective Models

Stability indicator \_\_\_\_\_ (green)

> Mode selector – switch



Operation indicator (orange) Sensitivity adjuster Distance-settable Sensor BGS Models E3Z-LL



Operation indicator (orange) Mode selector switch

## Safety Precautions

## Refer to Warranty and Limitations of Liability on page 20.

## ✓! Varning

This product is not designed or rated for ensuring safety of persons. Do not use it for such purpose.



To ensure safe use of laser products, do not allow the laser beam to enter your eye. Direct exposure may adversely affect your eyesight.

## ▲ Caution

Do not connect an AC power supply to the Sensor. If AC power (100 VAC or more) is supplied to the Sensor, it may explode or burn.



## Precautions for Safe Use

Be sure to abide by the following precautions for the safe operation of the Sensor.

## **Operating Environment**

Do not use the Sensor in locations with explosive or flammable gas.

## Wiring

## Power Supply Voltage and Output Load Power Supply Voltage

Make sure that the power supply to the Sensor is within the rated voltage range. If a voltage exceeding the rated voltage range is supplied to the Sensor, it may explode or burn.

### **Power Supply Voltage**

The maximum power supply voltage is 26.4 VDC. Applying a voltage exceeding the rated range may damage the Sensor or cause burning.

### Load

Do not use a load that exceeds the rated load.

### Load Short-circuiting

Do not short-circuit the load, otherwise the Sensor may be damaged or it may burn.

### **Connection without Load**

Do not connect the power supply to the Sensor with no load connected, otherwise the internal elements may explode or burn. Always connect a load when wiring.

## Correct Use

Do not use the product in atmospheres or environments that exceed product ratings.

#### **Usage Environment**

## Water Resistance

The Sensor is rated IP67. Do not use it in water, in the rain, or outdoors.

#### **Ambient Environment**

Do not install the product in the following locations. Doing so may result in product failure or malfunction.

- · Locations subject to excess dust and dirt
- · Locations subject to direct sunlight
- · Locations subject to corrosive gas
- · Locations subject to organic solvents
- · Locations subject to shock or vibration
- · Locations subject to exposure to water, oil, or chemicals
- · Locations subject to high humidity or condensation

## Designing

### **Power Reset Time**

The Sensor is ready to operate 100 ms after the Sensor is turned ON. If the load and Sensor are connected to independent power supplies respectively, be sure to turn ON the Sensor before supplying power to the load.

## Wiring

### **Avoiding Malfunctions**

If using the Sensor with an inverter or servomotor, always ground the FG (frame ground) and G (ground) terminals, otherwise the Sensor may malfunction.

### Mounting

### Mounting the Sensor


- If Sensors are mounted face-to-face, make sure that the optical axes are not in opposition to each other. Otherwise, mutual interference may result.
- Always install the Sensor carefully so that the aperture angle range of the Sensor will not cause it to be directly exposed to intensive light, such as sunlight, fluorescent light, or incandescent light.
- Do not strike the Photoelectric Sensor with a hammer or any other tool during the installation of the Sensor, or the Sensor will lose its water-resistive properties.
- Use M3 screws to mount the Sensor.
- When mounting the case, make sure that the tightening torque applied to each screw does not exceed 0.54 N·m.

## Metal Connectors

- Always turn OFF the power supply to the Sensor before connecting or disconnecting the metal connector.
- · Hold the connector cover to connect or disconnect it.
- Secure the connector cover by hand. Do not use pliers, otherwise the connector may be damaged.
- Use a tightening torque of 0.3 to 0.4 N·m for M8 connectors and 0.4 to 0.5 N·m for M12 connectors. Vibration may cause the connectors to become loose and reduce the degree or protection is the tightening torque is not sufficient.


#### Mounting Direction for Distance-settable Models

 Make sure that the sensing side of the Sensor is parallel with the surface of the sensing objects. Normally, do not incline the Sensor towards the sensing object.




If the sensing object has a glossy surface, however, incline the Sensor by  $5^{\circ}$  to  $10^{\circ}$  as shown in the illustration, provided that the Sensor is not influenced by background objects.


 If there is a mirror-like object below the Sensor, the Sensor may not operate stably. Therefore, incline the Sensor or separate the Sensor from the mirror-like object as shown below.



• Do not install the Sensor in the wrong direction. Refer to the following illustration.




Install the Sensor as shown in the following illustration if each sensing object greatly differs in color or material.



## Adjusting Distance-settable Models

**Indicator Operation** 




Note: If the stability indicator is lit, the detection/no detection status is stable within the rated ambient operating temperature (-10 to 55°C).


### Inspection and Maintenance


#### Cleaning

Never use paint thinners or other organic solvents to clean the surface of the product.

## Dimensions (Unit: mm)







## WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

#### LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

#### SUITABILITY FOR USE

THE PRODUCTS CONTAINED IN THIS DOCUMENT ARE NOT SAFETY RATED. THEY ARE NOT DESIGNED OR RATED FOR ENSURING SAFETY OF PERSONS, AND SHOULD NOT BE RELIED UPON AS A SAFETY COMPONENT OR PROTECTIVE DEVICE FOR SUCH PURPOSES. Please refer to separate catalogs for OMRON's safety rated products.

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the product.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

#### PERFORMANCE DATA

Performance data given in this document is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

### CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the product may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

### DIMENSIONS AND WEIGHTS

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

### ERRORS AND OMISSIONS

The information in this document has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

### **PROGRAMMABLE PRODUCTS**

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

Cat. No. E368-E2-01-X

In the interest of product improvement, specifications are subject to change without notice.

## **OMRON EUROPE B.V.**

Wegalaan 67-69, NL-2132 JD, Hoofddorp, The Netherlands Phone: +31 23 568 13 00 Fax: +31 23 568 13 88 www.eu.omron.com





Below is a list of articles with direct links to our shop Electric Automation Network where you can see:

- Quote per purchase volume in real time.
- Online documentation and datasheets of all products.
- Estimated delivery time enquiry in real time.
- Logistics systems for the shipment of materials almost anywhere in the world.
- Purchasing management, order record and tracking of shipments.

## To access the product, <u>click on the green button</u>.

Product	Code	Reference	Product link
Monitoring relays, Accessory level	145392	PH-2 1M	Buy on EAN
Security Product, Mechanical lock 2NC / 1NO + 3NC LED IP67 M20 metal connector Special wrench	382617	D4SL-N4PDA- D4N	Buy on EAN
Proximity Sensor, Inductive M8 Inox Flush 1mm Long 3h 5m cable NPN NC Lite	375990	E2B-S08LS01- WP-C2 5M	Buy on EAN
Photoelectric sensor, Mirror 23,5x40mm	356189	E391-50	Buy on EAN
	117914		Buy on EAN
Monitoring relays, level regulator	159891	61F-GP-N AC100	Buy on EAN
	169470		Buy on EAN
Temperature controller, 1/8DIN (48 x 96mm), relay output, thermocouple/PT100 input, heater burnout alarm	182401	E5EN- R3HMT-500 AC100-240	Buy on EAN
Photoelectric sensor, 60x18mm rectangular mirror. 2 mounting slots	356163	E39-R43	Buy on EAN
	136014		Buy on EAN
Total/time counter, DIN72x36mm, 100-240VAC, LCD, 6- digit, 30cps or 5kcps, NPN/PNP input, manual reset	119573		Buy on EAN
Total/time counter, DIN72x36mm, 12-24VDC, LCD, 6- digit, 30cps or 5kcps, NPN/PNP input, manual reset	119571		Buy on EAN
Total counter, DIN72x36mm, 12-24VDC, LCD, 8-digit, 30cps or 5kcps, NPN/PNP input, manual reset	119576		Buy on EAN
Total/time counter, DIN72x36mm, 12-24VDC, LCD, 6- digit, 30cps or 5kcps, NPN/PNP input, manual reset	119574		Buy on EAN

Counter, plug-in, 11-pin, DIN48x48mm, IP66, 4 digits, multifunction: 1-stage & total, SPST-NO 3A relay output, 12-24VDC/24VAC supply, 12VDC aux supply	119579		Buy on EAN
	118799		Buy on EAN
Control System, Power Supply Slot Cover Rack RV07	225308	WES-TP10	Buy on EAN
Basis for relay connection Barras trans. G2RV Red 3Term	225337	P2RVM-030R	Buy on EAN
	157089		Buy on EAN
Miniature Race Final, 5A SPDT Plunger needle Faston FO = 50GF	146453	VX-5-1C23	Buy on EAN
Output unit for K3N basic models only, 0-10VDC	146530		Buy on EAN