### **DATASHEET - NZM1-XFI30R**



Earth-fault release, 30mA, 3p, right

Part no. NZM1-XFI30R Catalog No. 104603 Alternate Catalog NZM1-XFI30R



**Delivery program** 

| Description      | Earth-fault release to IEC/EN 60947-2 not UL/CSA approved Suitable for use in three- and single-phase systems Pulse-current sensitive type A according to core-balance principle For 3 pole NZM1 circuit-breakers and N1 switch-disconnectors Supply voltage-dependent Ue = $200 - 415 \text{ V}$ 50/60 Hz Control knobs, sealable. Fitted on the right side up to $I_n = 160 \text{ A}$ at $I_{Cu} = 50 \text{ kA}$ |
|------------------|--|
| Contact sequence | $\sim$   |
| For use with     |  |
| For use with     | NZM1<br>N(S)1  |
| Pole             | 3 pole   |

#### Notes

With  $I_{\triangle n}$  = 0.03 A: delay time  $t_{\nu}$  always fixed setting at 10 ms.

Alarm message > 30 %  $I_{\triangle n}$  by yellow LED.

Trip indication max. 2 auxiliary contacts (HIAFI) can be fitted by user: N/O = M22-K01, N/C = M22-K10 are reset via the reset toggle lever.

If the trip-indicating auxiliary contact in the fault current block is used, the N/C contacts operates as a N/O contact and the N/C contact operates as an N/O contact.

Double contact not permissible.

 $Not in \ combination \ with insulated \ enclosure \ or \ main \ switch \ assembly \ kit \ for \ side \ panel \ mounting \ with \ mounting \ bracket$ 

NZM1-XFI...R can not be used in combination with lower cover NZM1-XUSA.

NZM1-XF1...U not in combination with shunt or undervoltage release, early-make auxiliary contacts.

Rated ultimate short-circuit breaking capacity is determined by the fitted NZM1, NS1.

If a switch-disconnector N1 is applied by the back-up fuse to be used  $\longrightarrow$  Technical data.

# Technical data

| Electrical  |                 |      |  |
|---|-----------------|------|--|
| Standards   |                 |      | IEC/EN 60947-2<br>IEC/EN 60947-2 annex B                       |
| Sensitivity   |                 |      | Pulse-current sensitive as per core-balance principle (type A) |
| Min. operating voltage  | U <sub>e</sub>  | V    |  |
| or detection of fault currents type A/AC  |                 |      | 80 V (dependent on mains voltage)                              |
| Suitability for the application   |                 |      | In three- and single-phase systems                             |
| Rated operational voltage   | U <sub>e</sub>  | V AC | 200415 (3~)  |
| Rated frequency   | f               | Hz   | 50/60  |
| Number of poles   |                 |      | 3-pole   |
| Rated current range   | In              | Α    | 15160  |
| Rated fault currents  | I $_{\Delta n}$ | Α    | 0.03   |
| Detection range of the fault current  |                 |      | 50/60 Hz   |
| Rated ultimate short-circuit making capacity and rated ultimate short-circuit breaking capacity | $I_{\Delta m}$  | Α    | = I <sub>CU</sub>  |
| Mechanical shock resistance (IEC 60068-2-27)  |                 |      | 20 (half-sinusoidal shock 20 ms)                               |
| Lifespan, mechanical (50 % with fault current)  | Operations      |      | 20000  |
|   |                 |      |  |

### **Mechanical**

| in contain car           |                 |                                      |
|--------------------------|-----------------|--------------------------------------|
| Standard front dimension | mm              | 45                                   |
| Mounting                 |                 | on the right side                    |
| Mounting position        |                 | Vertical and 90° in all directions   |
| Supply                   |                 |                                      |
|                          |                 | NZM1 from above                      |
| Degree of protection     |                 | IP20 in the operating component area |
| Ambient temperature      |                 | -5 - +40                             |
| Terminal capacity        |                 |                                      |
| Flexible without ferrule | mm <sup>2</sup> | wie NZM1 Standardklemme              |
| flexible with ferrules   | mm <sup>2</sup> | such as NZM1 standard terminal       |

# Design verification as per IEC/EN 61439

| Doorgii vormoution do por 120/211 or 100   |    |  |
|--|----|--|
| Technical data for design verification   |    |  |
| Operating ambient temperature min.   | °C | -5   |
| Operating ambient temperature max.   | °C | 40   |
| IEC/EN 61439 design verification   |    |  |
| 10.2 Strength of materials and parts   |    |  |
| 10.2.2 Corrosion resistance  |    | Meets the product standard's requirements.   |
| 10.2.3.1 Verification of thermal stability of enclosures   |    | Meets the product standard's requirements.   |
| 10.2.3.2 Verification of resistance of insulating materials to normal heat   |    | Meets the product standard's requirements.   |
| 10.2.3.3 Verification of resistance of insulating materials to abnormal heat and fire due to internal electric effects |    | Meets the product standard's requirements.   |
| 10.2.4 Resistance to ultra-violet (UV) radiation   |    | Meets the product standard's requirements.   |
| 10.2.5 Lifting   |    | Does not apply, since the entire switchgear needs to be evaluated.   |
| 10.2.6 Mechanical impact   |    | Does not apply, since the entire switchgear needs to be evaluated.   |
| 10.2.7 Inscriptions  |    | Meets the product standard's requirements.   |
| 10.3 Degree of protection of ASSEMBLIES  |    | Does not apply, since the entire switchgear needs to be evaluated.   |
| 10.4 Clearances and creepage distances   |    | Meets the product standard's requirements.   |
| 10.5 Protection against electric shock   |    | Does not apply, since the entire switchgear needs to be evaluated.   |
| 10.6 Incorporation of switching devices and components   |    | Does not apply, since the entire switchgear needs to be evaluated.   |
| 10.7 Internal electrical circuits and connections  |    | Is the panel builder's responsibility.   |
| 10.8 Connections for external conductors   |    | Is the panel builder's responsibility.   |
| 10.9 Insulation properties   |    |  |
| 10.9.2 Power-frequency electric strength   |    | Is the panel builder's responsibility.   |
| 10.9.3 Impulse withstand voltage   |    | Is the panel builder's responsibility.   |
| 10.9.4 Testing of enclosures made of insulating material   |    | Is the panel builder's responsibility.   |
| 10.10 Temperature rise   |    | The panel builder is responsible for the temperature rise calculation. Eaton will provide heat dissipation data for the devices. |
| 10.11 Short-circuit rating   |    | Is the panel builder's responsibility. The specifications for the switchgear must be observed.                                   |
| 10.12 Electromagnetic compatibility  |    | Is the panel builder's responsibility. The specifications for the switchgear must b observed.                                    |
| 10.13 Mechanical function  |    | The device meets the requirements, provided the information in the instruction leaflet (IL) is observed.                         |


### **Technical data ETIM 7.0**

Low-voltage industrial components (EG000017) / Residual current release for power circuit breaker (EC001021)

Electric engineering, automation, process control engineering / Low-voltage switch technology / Circuit breaker (LV < 1 kV) / Fault current switch for circuit breakers (ecl@ss10.0.1-27-37-04-11 [AKF009013])

| [AKF009013])                               |    |             |
|--|----|-------------|
| Rated control supply voltage Us at AC 50HZ | V  | 200 - 415   |
| Rated control supply voltage Us at AC 60HZ | V  | 200 - 415   |
| Rated control supply voltage Us at DC      | V  | 0 - 0       |
| Rated fault current                        | Α  | 0.03 - 0.03 |
| Max. power on-delay time                   | ms | 30          |
| Delay adjustable                           |    | No          |
| Max. rated operation voltage Ue            | V  | 415         |

# **Dimensions**



# **Additional product information (links)**

IL01219028Z (AWA1230-2331) Residual current device NZM1, mounting right

IL01219028Z (AWA1230-2331) Residual current ftp://ftp.moeller.net/DOCUMENTATION/AWA\_INSTRUCTIONS/IL01219028Z2016\_02.pdf device NZM1, mounting right