











Mounting plate, steel, galvanized, D=3mm, for CI45 enclosure

Part no. M3-CI45
Catalog No. 003036
EL-Nummer (Norway) 4132189

Delivery program


Product range		xEnergy Safety Ci
Basic function		Basic enclosures
Product function		Mounting system
Accessories		Mounting plates
Single unit/Complete unit		Modular system
Material		Sheet steel 3 mm, unperforated, galvanized
Information about equipment supplied		Including 4 captive fixing screws
For use with		CI45

Notes				
Mounting depth with mounting plate	CI...-125...	CI...-150...	CI...-200...	CI...-250...
Mounting depth with mounting rail 7.5 mm or 15 mm				
Enclosure depth				

Technical data ETIM 7.0

Energy distribution systems (EG000015) / Mounting plate for distribution board (EC000213)		
Electric engineering, automation, process control engineering / Electrical insulation and connecting material / Energy distribution system / Mounting plate for distribution board (ecl@ss10.0.1-27-40-06-39 [AC0553011])		
Height	mm	455
Width	mm	330
Material		Steel
Surface protection		Galvanized
Perforated		No

Dimensions



Mounting plate M3-....: 3 mm thick

Additional product information (links)

http://www.eaton.eu/DE/ecm/idcplg?IdcService=GET_FILE&allowInterrupt=1&RevisionSelectionMethod=LatestReleased&noSaveAs=0&Renderit model certification xEnergy Safety Ci

http://www.eaton.eu/DE/ecm/idcplg?IdcService=GET_FILE&allowInterrupt=1&RevisionSelectionMethod=LatestReleased&noSaveAs=0&Renderit Save time – we assist you with expert pre-assembly

http://www.eaton.eu/DE/ecm/idcplg?IdcService=GET_FILE&allowInterrupt=1&RevisionSelectionMethod=LatestReleased&noSaveAs=0&Renderit product information xEnergy Safety Ci

<http://www.eaton.eu/DE/Europe/Electrical/CustomerSupport/ConfigurationTools/TCTool/index.htm> tool for calculating the power loss for switching device combinations

<http://www.eaton.eu/DE/Europe/Electrical/CustomerSupport/ConfigurationTools/xEnergyMainSupport/index.htm> configurator - xEnergy family